



R16380
 BARNES
 13 LAMBTON RD
 SW 20.

2 2.

IS THIS TIGHT. CHECK MEASURE AND IF 390 WON'T MAKE IT OVER THE NOSING TO THE TREADS OF WINDER 1, MOVE IT OVER AND SEAM IN ALCOVE ON OPPOSITE WALL.