

# P26921 - Bloomfield (Fitting Instructions)

Monday, 13 June 2016

Prepared For Sandi Bloomfield

## Identified 4 Issues

Nigel Symonds

Mr Carpet Ltd





### Alarm Instruction On Entry

Hold key fob against top L/H corner to turn alarm off



### Sub-floor prep

Take up top layer of 6mm ply & both layers of 2mm rubber flooring. Lay new 6mm ply & screed over with Stoppagap 700 Flex. Lay tiles broken bond with 5mm feather strip between tiles



### Tile Direction

Lay Opus - SP213 Urbus broken bond with 5mm AF05 feature stripping between tiles. Use universal adhesive due to South East facing Velux windows in roof



### Alarm Instruction On Exit

Hold key fob against top L/H corner & then press 'Yes' to set alarm