

1/11 = Take up ex CRT, v/lay + s/lc
 Hardboard floor & tape over all
 Joints with 2" s/s tape + Seal
 Gaps under skirting with mastic
 3/11 = Fit padding, v/lay + carpets

mrcarpet
 DESIGNERS FOR FLOORS
 Job No: P26696
 Name: White
 Address:
 Tel: (141)
 Sheet: 01

Front

