

- CUT NEW PIECE FOR MANHOLE COVER & TURN UNDER AT SIDES AGAIN BUT MAKE SURE THE PIECE IS SLIGHTLY SMALLER THAN THE SPACE SO IT FITS IN WITHOUT TOUCHING THE SURROUNDING PIECE.
- WILL NEED TO SCRAPE OFF UNDERLAY THAT IS BENEATH CURRENT MANHOLE SECTION AS IT IS STUCK HARD.
- MAKE SURE NEW PIECE IS NOT STUCK HARD SO IT CAN BE LIFTED OFF ENTIRELY IF NECESSARY (USE TACKIFIER?)
- NEATEN UP PERIMETER AS IT IS SLIGHTLY BULGING IN SPOTS - CUSTOMER NOTED LEFT HAND WALL (WITH BATHROOM OFFIT) IN PARTICULAR.
- FIT SATIN CHROME TILE LIP TO BATHROOM TILES.
- PLEASE TIGHTEN 4TH STEP FROM VERY BOTTOM OF BASEMENT FLIGHT OF STAIRS.

Job No: P29073
 Name: DUNLOP
 Address: 10/F
 Tel:
 Sheet: of

