

FITTING INSTRUCTIONS

R18892 – McCluskie

Adrian -19/05/23

- Change Living room doorbar from S/Nap to Tile Edge (DZ9-Black) & tap it down so it's flush with the LVT in the hall (same as you did on the GF Playroom)
- (The builder will cut the LVT & screed back to the line of the door beforehand)
- Fit a 6mm shim to raise carpet height at junction with tiled floor in Master Bedroom ensuite
- Re-Stick gripper at junction with tiles at top floor shower room doorway as the existing has come loose. (Prime with spray adhesive before applying Fastset to ensure a good bond)
- Re-stretch carpet back into loft bedroom doorbar where it's coming away & secure with spray adhesive to prevent reoccurrence
- Re-dress 1st flight of stairs which are a loop short on the left-hand side. If they can't be redressed successfully, please use spare carpet left on site previously to replace them
- Generally, stretch, tuck down & tidy up the main landing where there are loops missing around the newel post etc

Please have a walk around the job with the customer when finished to make sure she's 100% happy before leaving

Many thanks

Nigel