

R19341 Cheema

Warranty Call Instructions

(PLEASE READ BEFORE ATTENDING)

- 1) Replace 3 Satin brass D/Naps & 1 x Satin Brass angle edge on 1st floor. Please inspect the bars for damage prior to fitting & be extra careful not to mark them during installation (I've allocated 4 D/Naps just in case)
- 2) Attend to hard lumps under the 2 first floor front bedrooms (see plan below for lump locations)
- 3) Re-stretch 1st floor landing to remove ridge / lump
- 4) Tighten up top stairs to remove fullness and generally check the job over to ensure it's as tight as possible before leaving

Please walk through the job with Mr Cheema to make sure he is 100% happy before leaving. Thank you

