

S27888 Hill

Attend Notes

1. Tidy up landing at front bedroom doorway where bulging.
2. Re-fit (spray carpet onto gripper) against slope in front bedroom where carpet is coming up.
3. Tidy up finish of carpet behind right hand radiator pipe to front bedroom.
4. Re-stretch carpet onto gripper in master bedroom behind door and in fire place alcove.
5. Fit Satin Ali Z/Z at family bathroom.
6. Replace Satin Ali Z/Z at en-suite doorway as original bar has been cut short.
7. Tidy landing at the end of the banisters where carpet is lifting slightly and at bedroom doorway (1st left at top of stairs) where carpet is bulging.