

S29467
PARTER

FIT FROM CENTRE OF ARCHWAYS
MAKING SURE THEY ARE STRAIGHT
HERE. CUSTOMER IS WORRE THAT
IT WILL RUN OUT IN FRONT OF
KITCHEN UNITS + WALL IN FRONT
OF FRONT DOOR.

- WOODEN SUB FLOOR
NEEDS PUT
- CONC SUB FLOOR
FIT OVER BUILDERS
DEEP

