

## S29816 Madath – Alan Warranty Call Checklist

1. Tighten loose carpet into bar to top bedroom
2. Tighten loose carpet into bar to 1<sup>st</sup> floor rear bedroom
3. Lump to coir matting. Cut matting slightly to get rid of lump
4. Fit Anod S/N instead of current turn on main landing (this is not a warranty issue as we instructed you to do this however the customer would prefer a bar)