

(\*) ALAN FRIDAY 13/4/2018

**S29816 Madath - Alan Warranty Call Checklist**

1. Tighten loose carpet into bar to top bedroom
2. Tighten loose carpet into bar to 1<sup>st</sup> floor rear bedroom
3. Lump to coir matting. Cut matting slightly to get rid of lump
4. Fit Anod S/N instead of current turn on main landing (this is not a warranty issue as we instructed you to do this however the customer would prefer a bar)

ALAN PLEASE ENSURE  
ALL DONE  
THANKS

---