

S30600 Kraehe – Adrian Wednesday 18th December

1. Cut en-suite carpet in at door bar where left long previously
2. Piece in underlay at bathroom door where it is short
3. Restretch lounge ALL edges