

Kenn Wed 15/5/19

mrcarpet
S30766

① Knap seam in main Bed (Dressing room)

② Top Floor Main Bed at bathroom door

Pull carpet back, take away tile lip

The bedroom sub floor slopes against the bathroom floor. Adjust existing Easi Shim by cutting diagonally in order to leave 10 or 11mm below bathroom floor. + Get

Satin Aluminium Zig Zag

③ Top Rear bed Get 2 x 9mm Shims + Satin Al Zig Zag

④ Top Floor Main Bed fit Satin Al Shim

⑤ 1st Floor F. Bed 3 + R Bed 4 Put 2 x Satin Al Shims

⑥ 1st Floor R. Bed Put Satin Al Shim

Fit runner

Fit Top Stairs