



- 8X STAIRS = 46X76
- W3 = 63X86 -
- W4 = 70X105 -
- W5 = 67X73 -
- 1X STAIR = 45X75
- BLW 1 = 45X95 -
- BLW 2 = 63X116 -





FOR FITTER

TO MAKE  
IN TO  
Z BARS

## Technical

32

**Post fit cleaning tips: See page 92**

### Product

- The Premier Trim DoubleZ™9 range of door bars are manufactured using a base material of solid brass for a high quality installation.
- The Premier Trim DoubleZ™9 range are available in three lengths: 90cm, 180cm and 270cm.

### Fitting

- The Premier Trim DoubleZ™9 range can be used for a carpet to carpet and carpet to hard floor installations due to an ingenious design feature.
- To transform the DoubleZ™9 into a Z Bar simply score along the peel line on the back of the base plate with a Stanley Knife and peel away with a pair of pliers.



ANY QUESTIONS

Please call 01207 591176 For friendly expert advice.

- 'Nap' down the DoubleZ™9 to give the carpet a firm grip on the pins.
- To 'Nap' simply use a block of wood wrapped in carpet and then gently hammer the block against the top of the trim.



- For underlays over 6mm use the MDF strips supplied to provide a convenient raised base for the DoubleZ™9 or Z Bar.
- The MDF strips should be cut into sections then and placed at the fixing points and nailed through.



### Care and Maintenance

- **Satin Brass and Polished Brass Trims** Lemon wipes will remove light tarnishing. However to keep the brass like new these two finishes will need to be polished from time to time with a propriety brass polish. Ensure that you follow the instructions on the tin and protect your flooring during polishing.
- **Satin Nickel, Chrome, and Brushed Chrome** Lemon wipes will remove light tarnishing. These finishes will need to be polished from time to time with a propriety metal polish. Ensure that you follow the instructions on the tin and protect your flooring during polishing.
- **Pewter, Antique Bronze and Antique Brass** Lemon wipes will remove light tarnishing. If these finishes become contaminated the only option is to polish them with a propriety metal polish and allow them to age again naturally. Ensure that you follow the instructions on the tin and protect your flooring during polishing.