


S30196

FORBES RIX DESIGN



THIS FLIGHT TO BE 64 cm WIDE

NATURAL LOOP


TOP STAIRS

PLAN ① 2.00 x 4m

NATURAL LOOP

MAIN STAIRS

PLAN ② 5.00 x 4m




THIS FLIGHT TO BE SHAPED WINDERS AS PER LAYOUT

MARGO SELBY STRIPE

SIDE STAIRS

PLAN ③ 2.40 x 4m




THIS FLIGHT TO BE 60 cm of STRAIGHTS

+ SHAPED AS SHOWN ON LAYOUT TO WINDERS

TOP STAIRS (64cm WIDE ON STRAIGHTS)

Riser	20	83
G @	44	83
1/4	121	100
10e	44	84




FORBES RIX

- WOOD FLOORS
- NO U/D
- NEEDS S/E
- CONFIRM RUNNER WIDTHS
- 10cm GAP @ SIDES OF RUNNER

MAIN STAIRS

Riser	20	120
W1	63	115
W2	60	117
W3	60	125
W4	56	140
W5	53	155
W6	66	170
W7	60	150
W8	60	120
W9	55	115
W10	55	115
W11	55	120
W12	55	130
W13	55	130
W14	60	155




- WOOD FLOORS
- NO U/D
- NEEDS S/E
- CONFIRM RUNNER WIDTH + SHAPE
- 10cm GAP ON INTERNAL OF RUNNER + OPEN EXTERNALS.

W15	75	175
W16	60	140
W17	60	130
W18	60	120
W19	60	110
W20	60	120

SIDE STAIRS (60 cm WIDE and STRAIGHTS) FORCES RIX.

Riser	20	80
10 e	45	80
W1	65	97
W2	70	120
W3	80	80
3 e	45	78




- WOOD FLOOR
- NO UD
- NEEDS S/E
- RUNNER TBC

10cm GAP EITHER SIDE WITH OPEN EXTERNALS ON HANDERS.

BASEMENT STAIRS

WOOD →	1 e	48	85
CONC →	1 e	48	85
CONC →	7 e	45	70



- TOP STEP WOOD
- OTHER STEPS CONC
- NO UD
- NEEDS S/E
- RUNNER TBC